



Support bearing

The support bearing are welded to the swap body frame. They are used to mount the support legs when they are not in use.



SL 550 V



SL 555 V

Selection table / Available versions

Weight (kg)	Order No.	Drawing No.
2.7	SL 550 V	640.771.000
1.8	SL 555 V	641.223.000